# LIST

OF

## **PARTS**



MACHINE No. 112-1

THE SINGER MANUFACTURING COMPANY

COPYRIGHT, U. S. A., 1922, BY THE SINGER MANUFACTURING CO.
ALL RIGHTS RESERVED FOR ALL COUNTRIES

#### INDEX

PA	AGE
ACCESSORIES	13
COOT LIFTER PARTS	13
RON BASE	12
NEE LIFTER PARTS	13
Aachine No. 112-1	7
Numerical List of Parts	17
ABLE SUPPORT PARTS	14
GREAD UNWINDER	15

### INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts. must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated. .
- B. Polished and Plated
- C. Hardened only.
- D. Polished only.
- E. Soft, not Polished.
- F. Hardened and Polished.
- G.
- H. Blued.
- J. Plated only.
- K. Hardened and Plated.
- L. Brass or Gilt.
- M. Oxidized.
- P. Japanned.
- R. Parkerized

These letters MUST BE USED when they appear in the list, and AFTER the number as in the list.

In this series

- 1 to 1500 and 50001 to 51500 are Screw Numbers.
- 1501 to 1800 are Nut Numbers.
- 1801 to 2000 are Roller Numbers.
- 2001 to 50000 and 52001 and upward are numbers of Machine Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (\*) are furnished only when repairs are made at factory.

#### LIST OF PARTS COMPLETE

**FOR** 

#### **MACHINE No. 112-1**

FOR WIRING LADIES' HATS, WITH AN OVERSEAMING ZIGZAG STITCH, THROW OF NEEDLE UP TO 18 INCH. DROP FEED, REGULARLY FITTED WITH SWING OUT WORK GUIDE. BALANCE WHEEL AND NEEDLE BAR LEVER ECCENTRIC No. 64807.

NO.	PLATE	NAME
64801		Arm, upper and lower (solid)
34461	8500	" End Cover and Belt Guard
207 p	8507	" Rotary Shaft " Screw
64802	8500	" Rotary Shaft
64803	8501	" " Bushing (front)
4036c	8507	" " " SetScrew
64804	8500	" " " Flanged Bushing (back)
		with 64805
64805	8501	Arm Rotary Shaft Flanged Bushing (back)
		Oil Pad (braided cotton)
1036c	8507	Arm Rotary Shaft Flanged Bushing (back)
		Set Screw
64806	8501	Arm Rotary Shaft Gear with two 200F
$200 {\rm F}$	8501	" " Set Serew
64807	8500	Balance Wheel and Needle Bar Lever
		Eccentric with 430c and 1285c
1285c	8507	Balance Wheel and Needle Bar Lever
		Eccentric Position Serew
430c	8507	Balance Wheel and Needle Bar Lever
		Recentrie Set Serew
64808	8500	Face Plate
$330_{\rm F}$	8507	" " Screw
64809	8500	Feed Bar
64810	8501	" " Connecting Link
428c	8501	" " Hinge Screw
64811	8509	" " Cover
176г	8507	" " Serew
64812	8501	" " Hinge Stud
452c	8507	" " Set Screw
32055	8501	" Connecting Rod with 1012E, 42009
		and two 1057E

	ATE			NΛ				
1012e - 8			Connect					
121/1/1/	-	"	"		"			
	50 I							<b></b> .
	502		Dog					
190b/8	507	44	" Ser	ew.				
32057 - 8	501		Eccentr					
452c 8	507	44	44					
64814 - 8	501		Lifting 1					
64815 - 8	501	44	44	66	C	onnec	tion wi	th 171e
		:1116	1 59019.				<b>.</b>	
171E S	50I	Feed	Lifting 1	Eccen	tric	Conn	ection	Adjust-
		ing	Screw.					
59019 8	501	Feed	Lifting	Eccen	tric	Con	nection	Gib
50562c 8		"	"	44			"	Hinge
0,00,00	,,,,,	Ser	ew					
1520E-8	501	Reed	Lifting	Eccer	rtrio	ı Con	nection	Hinge
11)4()11 (	30//1	Ser	ew Nut	130001			11000101	
452c 8	507	Mand	Lifting	l'acco	teia	Posit	ion Ser	ww
462c 8		44	in ong	1100011	0110			
	5503 5500		66	D. Alex	٠,,,			
.,		"	"	rock)	3115L			· · · · · · ·
	3501	"	"	"	"	17(6		t Serew
1036c 8		"	"	"			120	:k) with
61818 8	3503							
		157	Έ			1 6	()	/11.\
157в 8	\$503	Feed	Lifting	Roc	K B	Hitt	Crank	(Dack)
	. =	Cla	imping S	Screw		1 6		(6
64819 8	3503	Feed	Lifting	Roc	K D	mart,	Станк	(Hone)
		WIE	h 157E	and 4	280			(6
457⊭ 8	8503	Feed	Lifting	; Roc	K S	hait	Crank	(Front)
	. =	Ch	imping i	Screw	• • •			
1027c 8		Feed	Regulat	ting S	crev	N Still	d	
4627c 8			"			"		
	3503	"						her
	3500	"	Rockin	g Fra	me	with 1	four 45	2e
59211 - 8	3500	44	"			Hinge	e Pin	
64821 - 8	8503	46	"	"		"	"Bi	shing.
1036c 8	s507	"	46	44		"	"	" Se
		Sei	rew					
452c 3	8507	Feed	Rockin	g Frai	ne	Hinge	Pin Se	et Screw
36976	5698	Guid	e					
	5698	-64						
201 в		"	4.6	"	Se	rew.	0	
	8503	16	46	"		" 1	Vasher	
	5698	"	Shank					
907 p		"	1711211118	Him	 m	erew		
	5698	4.6	"	46	,4- 17	**	Washe	r
38070 г 1074в г		"	¥t1					
1074B	50U/		อเนเน					

	•
NO. PLATE	NAME
793в 8507	Guide Thumb Screw
7071 8503	" " Washer
36978 - 5698	Guide eomplete, Nos. 201B, 793B, 1074B,
	36976, 36977, 120210 and two 7071
64822 8503	Looper with 34418
64823 8503	" Gate
1240c 8503	" " Hinge Serew
64824 8503	" " Spring
111p 8503	" " Serew
64825 8503	" Shaft with 462c
64826 8503	" Carrier
64827 8503	" " Bushing
846c 8503	" " Set Serew
64828 8504	" " Pitman
0.0=0	" " Hinge Screw
1132F 8507	
F0F40 0F01	(left) Looper Shaft Carrier Pitman Hinge Serew
50562c 8501	Looper Shart Carrier Fitman Tringe Serew
	(right)
1520E 8501	Looper Shaft Carrier Pitman Hinge Serew
	(right) Nut
64829 8503	Looper Shaft Coupling with two 462c
462c 8501	Det Detew
462c 8501	" Set Serew
34418 8503	" Washer
64830 8505	Needle Bar (hollow) with 50165r and
	64850
64831 8505	Needle Bar Connecting Bracket with
	1056г and 50203E
50203E 8505	Needle Bar Connecting Bracket Clamping
	Screw
42055 8505	Needle Bar Connecting Link
40247 8505	" " " Hinge Pin
1056F 8505	" " " " Set
	Screw
64832 - 8504	Needle Bar Frame
64833 8504	" " Cam and Gear
64834 8504	" " " Cover
476p 8507	u u u u u u
	Screw
64835 8504	Needle Bar Frame Cam and Gear Stud
0.000	(eccentric)
64836 8505	Needle Bar France Cam and Gear Stud
32000	Collar with two 1259c
1259c 8505	Needle Bar Frame Cam and Gear Stud
12000 0000	Collar Set Screw
1036c 8507	Needle Bar Frame Cam and Gear Stud
10300 8507	Set Screw
	Det berew

8849 - 2

11

	,
NO. PLATE	
64837 8504	Needle Bar Frame Driving Lever
64838 8505	Connect-
	ing Link with 1012b and 59019
1012b 8501	Needle Bar Frame Driving Lever Connect-
	ing Link Adjusting Screw
59019 8501	Needle Bar Frame Driving Lever Connect-
	ing Link Gib
50562c 8501	Needle Bar Frame Driving Lever Connect-
	ing Link Hinge Serew
1520E 850I	Needle Bar Frame Driving Lever Connect-
	ing Link Hinge Serew Nut
64839 8505	Needle Bar Frame Driving Lever Hinge
	Stud
1036c 8507	Needle Bar Frame Driving Lever Hinge
	Stud Set Screw
64840 8505	Needle Bar Frame Guide
176F 8507	Derew
37583 8505	imge Stud
1036c 8507	Det Detem
64841 8504	1 man and a second
50562c 8501	" " " Hinge Serew " " " "
1520E 850I	
04040 0500	Nut
64842 8500	Needle Bar Frame Regulator with two
64839 8505	1120c  Needle Bar Frame Regulator Hinge Stud
64843 8505	" " " " " " "
04049 0000	Bushing
1259c 8505	Needle Bar Frame Regulator Hinge Stud
12000 0000	Bushing Set Screw
1984 8505	Needle Bar Frame Regulator Roller and
1904 0505	Screw Stud
C4044 0505	
64844 8505	Needle Bar Frame Regulator Stop Screw
220a 8505 7806 8505	u u u u u u
7500 5505	Washer
4400 0505	
1120c 8507	Needle Bar Frame Regulator Set Screw
1374c 8505	" " Regulating Screw Stud
1680c 8505	
	Nut
42290 8503	Needle Bar Frame Regulating Screw Stud
	Washer
64845 - 8509	Needle Bar Lever with 1056F and two
	1036c
42074 8505	Needle Bar Lever Ball Stud
1036c 8507	" " " Set Screw

310	PLATE	NAME
NO. 64846	8504	Needle Bar Lever Connecting Rod with
04940	0004	42059, 64847, 64848 and four 896E
*64847		Needle Bar Lever Connecting Rod Cap
.04941		(lower)
0045	8507	Needle Bar Lever Connecting Rod Cap
890E	8907	(lower) Serew
+ 10050		Needle Bar Lever Connecting Rod Cap
*42059		
000	0507	(upper)  Needle Bar Lever Connecting Rod Cap
890E	8507	
4000	0500	(upper) Screw
42077	8506	" " " " " " " " " " " " " " " " " " "
171F	8501	
2.212		Serew
64848	8501	Needle Bar Lever Connecting Rod Oil
21010	0504	Cup  Needle Bar Lever Hinge Stud
64849	8504	" " Collar with
64836	8505	
40.00	0505	two 1259c
1259c	8505	Needle Bar Lever Hinge Stud Collar Set
7000	0.00	Screw
1036c		Needle Bar Lever Hinge Stud Set Serew
64850	8505	" " Washer
50165F		
1728c		Needle Clamping Nut
64851	8506	Presser Bar
64852	8506	and 50203F
50000	OFOF	Presser Bar Guide Bracket Adjusting
50203ғ	8505	Screw
1454F	0500	Presser Bar Guide Bracket Clamping
1494F	8900	Screw
40000	0506	Presser Bar Guide Braeket Guide
42007	8506	" " " Set Serew
452c	8507	Presser Bar Lifter
32123	8506	" " " Hinge Stud
32235	8506	" " Set Screw
452c	-	" Roller and Screw Stud
51807	8506	" " Spring (flat)
64853	8504	" " Pin
54722	8506	1 111,
32175	8506	50ua
64854	8502	root with 200r and 04000
64878	8502	groove, for guiding a
		wire
64879	8502	Presser Foot for straight sewing and
		binding on wired hat frames
64880	8502	Presser Foot for overseaming chenille or
		other ornamental edging to straw braid

NO. PLATE	NAME
64855 8502	Presser Foot Extension
206f 8507	" " Serew
176ъ 8507	" " Screw
50132 р 8507	Pressure Regulating Thumb Screw
1543 р 8507	" " " Lock
	Nut
2102 - 8506	Tension Disc
1560c 8506	" Regulating Thumb Nut
50261c 8506	" Screw Stud
54738 - 8506	" Spring
64868 - 8506	" Thread Guide
19068 8506	Thread Controller Bracket
330ъ 8507	" Screw
32415 - 8506	" Guide Plate with 19070
19070 8506	" " " Stud
64856 - 8504	" Releasing Rod
59042 - 8506	" "Spring
22430 - 8506	" Eyelet (top of arm)
64857 - 8506	" Guard
152E 8506	" Screw
7071 8503	" " Washer
64858 - 8502	Throat Plate
64859 - 8502	" " Needle Hole Strip
64860 - 8502	" " " Guide
1094F $8502$	
	Serew
193F 8502	Throat Plate Needle Hole Strip Screw
1349F 8507	" Screw (large)
207F $8507$	" " (small)

### **IRON BASE**

NO.	PLATE			NA	ME					
64861	8509	Machine	Base	with	three	356	ic			
64862	8508	44	4.6	Bar.					٠.	
64863	8508	"	"	Foot	with	356	с			
3560	8507	44	"	44	Set 8	Screv	N			
3560	8507	"	"	Set 8	Screw					
42088	8507	44	Cush	ion (	felt).					
935E	8507	"	"	,	Screw					
64864	8509	Machine	Base	com	olete,	Nos	618	61,	tl	ree
		each 6	4862,	6486	3, wo	od s	erew	s 1	1/2	in.
		No. 12								

### **ACCESSORIES**

NO.	PLATE			N	AME					
	8508	Machi	ne Th	umb	Serev	v				
14063	8508	66		"	"	Sprin	g			
9842	8507	"		"	"	Wash	er			
36563	8508	Oiler (	coppe	r plat	ted) v	vith 36	564 .			
36564	8508	" 5	Spout,	5 in.	long	, with	1201	17.	٠.	· •
120117	8508					eather)				
26151	8508	Screw								
26485	8508			•						
8908	8508									
19079	8508	44	44	1728						 

### FOOT LIFTER PARTS

	NO.	PLATE	NAME
	6439		Chain, 36 in. to 45 in., with 56864 and
			56865
	N	ote: V	When ordering No. 6439 give gauge required.
	4879	8508	Chain Connecting Link
	56864	8508	" Hook (large)
	56865	8507	" (small)
	64865	8504	Lifting Lever
	7881	8507	" " Hinge Screw
,	64866	8500	" " Link
	1250c	8507	" " Guide Serew
	11841	8507	" " Hinge Screw
	19081	8507	" " Spring
	59051	8510	Treadle
	7585	8508	" Shaft
	14210	8510	" Stand
	59052	8510	Treadle complete, Nos. 4879, 7585, 14210,
	64867		59051 and four wood serews 1¼ in. No. 12

### **KNEE LIFTER PARTS**

	PLATE	NAME					
59055		Chain, length 18 in., with two 56865					
56865	8507	" Hook					

NO.	PLATE			N	AME		
64865	8504	Liftin	g Leve				
	8507	"	"		ige Screv		
64866	8500	"	"		k		
1250c		"	"	"		Screw.	
1184p		"	"	"	Hinge		
19081	8507	"	"	Spr	ing		
7124	8509	Rock	Shaft				
2764	8509	"			r (back)		
_,,,	1,500	ser			. 10		
16128	8509				er (front		
10120	0000				. 10		
16646	8509				Arm		
16647					e Arm		
10071					16646		
2766	8509				Arm Hu		
356c		"	"	"	" "		 w
2767	8509	46	"	"	Plate wi		
356c		"	"	"		t Screv	
6337	8509	44	" I	iftino	Bracke		
6338	8509	44	"	"	66	Hook	
356c	8507	"	44	"	"		Screw
356c	8507	"	"	"	"	Set S	
32134	8509	"	" 5	Spring	ζ		
2770	8509	"	"		Adjustin		
356c	8507	"	"	"	"		erew
2770	8509	"	" 5	Stop 1	Dog witl		
356c	8507	"	"	"		Screw.	
32135	8509	Rock	Shaft	comi	lete, N		
					128, 160		
64877					lete, No		
					2135, 59		

### **TABLE SUPPORT PARTS**


NO.	PLATE	NAME
41044	8510	Base with three wood screws 11/4 in. No. 14
41045	8510	Top with two wood screws 11/4 in. No. 14
41046	8510	Tube
		" Lock Nut
		Table Support Tube complete, Nos. 1726p
		and 41014 to 41046


### THREAD UNWINDER

FOR ONE LARGE SPOOL OR ONE LARGE
CONE OF THREAD

NO.	PLATE	NAME
27623	2836	Spool Pin
155c	8507	" Set Screw
41526	2836	" Rest
*60701		" 41526 with 155c and 1149c
41527		" 60701 with 27623
1149c	8507	" Set Screw
27940	2836	" Stand with 453c
41514	2836	" Weight, 4 in. diam., with 41515
41515	8507	" Centre Pin
27739	2836	Thread Cone (wood)
41630	2836	" Guard with 208E and 41569
41569	8507	" Eyelet
41637	2836	" Rod (lower)
41638	2836	" " (upper)
41639	2836	" " Coupling with two 456c
456c		" " Set Screw
41640		Thread Guard Rod complete, 30 in. long,
		Nos. 41637 to 41639
453c	8507	Thread Guard Rod Set Screw
208E	8507	" " Serew
41529	2836	Thread Unwinder complete, Nos. 27739,
		27940, 41514, 41527, 41630, 41640 and
		three wood screws, 1 in. No. 12

#### PLATE 2836-ONE-FOURTH SIZE





## PLATE 8501-FULL SIZE 64.803 Tummum 50562 H

